

## How to Update the QUICKCHECK<sup>webline</sup> Firmware

### NOTE

This technical note describes how to update the firmware of your QUICKCHECK<sup>webline</sup>.

PTW recommends downloading the saved measurement data from your QUICKCHECK<sup>webline</sup> to your PC before performing the update to the new firmware version.

1. Disconnect the power cable from your QUICKCHECK<sup>webline</sup>.
2. Make sure the device is turned off.
3. Connect the QUICKCHECK<sup>webline</sup> to your PC via RS232.
4. Start the **QUICKCHECKwebline Updater** on your PC.
5. Reconnect the power cable to your QUICKCHECK<sup>webline</sup>.
6. A message is displayed in the **QUICKCHECKwebline Updater** window, informing you that a connection to the QUICKCHECK<sup>webline</sup> has been established:
7. Follow the prompts in the dialog **QUICKCHECKwebline Updater** window.
8. The QUICKCHECK<sup>webline</sup> firmware will be updated. Do not close the **QUICKCHECKwebline Updater** window.
9. Once the update is complete, the message **Update successful** is displayed in the **QUICKCHECKwebline Updater** window.
10. Click the **Finish** button to close the window. Your QUICKCHECK<sup>webline</sup> firmware has been successfully updated.